





Aeropole, 05130 TALLARD
Tel:+33 (0)4 92 20 16 19 Fax:+33 (0)4 92 52 69 66
e-mail : contact@beringer-aero.com

NOMENCLATURE PIECES

Manuel référence :
BRG-ALTP-02

Référence document :
NP-STC-012

			Signature du responsable conception
STC-012 BERINGER STC for Extra 300			
Révisions	Date	Sujet	
00	26.01.2015	Creation document	
01	14.09.2015	Update	
02	09.11.2015	Update	
03	02.12.2016	Change of wheel P/N	
04	19 Oct 21	- Addition of the SensAIR system in option - Cotter pin added - Fairing plate and Screw added	



Aeropole, 05130 TALLARD
 Tel:+33 (0)4 92 20 16 19 Fax:+33 (0)4 92 52 69 66
 e-mail : contact@beringer-aero.com

NOMENCLATURE PIECES

Manuel référence :
BRG-ALTP-02

Référence document :
NP-STC-012

Part number	Description	Qty. Single seat	Qty. 2 seats
RF-018	Main wheel assembly	2	2
EA-002.2N	Brake assembly	2	2
FUS-009.3	Main wheel axle	2	2
ECR-002	Axle nut	2	2
V-FHC-003	Caliper Screw	4	4
NAS6604-43	Screw NAS6604-43	2	2
NAS6604-48	Screw NAS6604-48	6	6
MP-003.4N	Master cylinder	2	4
RV-001N	Reservoir	2	2
RDL-011	Spacer	4	8
AV-EXT-001.1	Brake line	-	2
AV-EXT-001.2	Brake line	2	2
HYD-022VC	Banjo 20° lateral	2	4
HYD-049VC	Banjo 90° lateral	-	2
HYD-003P	Banjo bolt	6	10
HYD-005B	Copper seal	20	20
L-V-004	Cotter pin	2	2
ZPA02	Safety wire	2	2
PT-008R	Right Fairing plate	1	1
PT-008L	Left Fairing plate	1	1
R-AP-012	Washer/Rondelle	6	6
V-CHC-082	1/4-28 UNF L=7/8" ASTM A574 + GEO_Screw/Vis Chc	4	4
V-CHC-040	M6-12 (Q12.9)_Screw / Vis	2	2
MS21044N-4	1/4"-28_self-locking nut	8	8
NAS1149F0432P	Washer AN4	8	8
-	Plastic straps – Rilsan 4x200	20	20
-	MIL-PRF-87257 sticker	2	2
-	Wrench adapter – Metric 5mm hex head	1	1
-	Wrench adapter – Metric 6mm hex head	1	1
TP-005	SensAIR on wheel 5"	(Option)	(Option)