


Caliper piston seals replacement

Revision	Description	Date	Approval
0	Creation	24 Feb 2023	

	Europe	USA
Contact:	BERINGER AERO 30, rue Pierre-Georges LATECOERE 05130 TALLARD – FRANCE	BERINGER AERO USA 18 Woods Lake Rd., Suite 102, Greenville SC 29607
Technical Support:	+33 492 201 619 support@beringer-aero.com	(864)-214-4274 support@beringer-aero.us

Table of content

1. GENERAL.....	2
2. BACKGROUND.....	2
3. OPERATING.....	2

1. GENERAL

The purpose of this service bulletin is to provide information regarding replacement of defective piston seals on calipers.

2. COMPLIANCE

This service bulletin is mandatory and must be applied immediately to all aircrafts concerned.

3. BACKGROUND

Some piston seals may show defects after some time of use, creating leaks on the caliper. The calipers concerned by this problem are the following:

Caliper P/N	Caliper S/N
EA-002E	38-21
	04-22
	04-22.2
	04-22.3
	18-22
	26-22
	26-22.5
EA-002.2E	21-22
	21-22.2
EA-003E	11-22
EA-003.2E	24-22
	24-22.2
EA-007E	001
EA-007.1E	001
EA-009.1E	17-22
	17-22.2
	17-22.3

4. OPERATING

BERINGER provide free repairing kits with Piston seals, copper seals and mounting grease for caliper pistons.

Refer to [MM-01-006](#) to replace piston seals.

Pistons don't need to be replaced.